



FUEL NOZZLE MRO CAPABILITIES

PW300 SERIES

ENGINE PROGRAM	DESCRIPTION	DELAVAN PART NUMBER	REFERENCE ENGINE OEM PART NUMBER
PW300	Fuel Nozzle Assembly	65022-2	01R30B2154
PW300	Fuel Nozzle Assembly	80001-8	30B4952-01
PW305	Fuel Nozzle Assembly	65186-1	31B4313-01
PW305	Fuel Nozzle Assembly	65186-2	01R31B4313-01
PW305	Fuel Nozzle Assembly	68266-1	31B5833-01
PW305	Fuel Nozzle Assembly	68266-2	31B5833-02
PW305	Fuel Nozzle Assembly	68266-3	31B5833-03,-04
PW305	Fuel Nozzle Assembly	68267-1	31B5834-01
PW305	Fuel Nozzle Assembly	68267-2	31B5834-02
PW305	Fuel Nozzle Assembly	68267-3	31B5834-03,-04
PW305	Fuel Nozzle Assembly	68268-1	31B5832-01
PW305	Fuel Nozzle Assembly	68268-2	31B5832-02, -03
PW305	Fuel Nozzle Assembly	68268-4	31B5832-04
PW305	Fuel Nozzle Assembly	70776-1	01R30B1754
PW305	Fuel Nozzle Assembly	70777-1	01R30B1755
PW306	Fuel Nozzle Assembly	169157	30B6456-01
PW306	Fuel Nozzle Assembly	155514	01R30B4951-01
PW306	Fuel Nozzle Assembly	155514	01R30B4951-01
PW306	Fuel Nozzle Assembly	155515	01R30B4952-01
PW306	Fuel Nozzle Assembly	155515	01R30B4952-01
PW306	Fuel Nozzle Assembly	68065-10	01R31B5209-01
PW306	Fuel Nozzle Assembly	68065-11	01R30B4670-02
PW306	Fuel Nozzle Assembly	68065-12	01R30B4670-01
PW306	Fuel Nozzle Assembly	68066-10	01R31B5208-01
PW306	Fuel Nozzle Assembly	68066-11	01R30B4669-02
PW306	Fuel Nozzle Assembly	68066-12	01R30B4669-01
PW306	Fuel Nozzle Assembly	68067-1	31B5207-01
PW306	Fuel Nozzle Assembly	68067-10	31B5207-10
PW306	Fuel Nozzle Assembly	68067-8	31B5207-08



FUEL NOZZLE MRO CAPABILITIES

PW300 SERIES

ENGINE PROGRAM	DESCRIPTION	DELAVAN PART NUMBER	REFERENCE ENGINE OEM PART NUMBER
PW306	Fuel Nozzle Assembly	68067-9	31B5207-09
PW306	Fuel Nozzle Assembly	80000-8	30B4951-01
PW306	Fuel Nozzle Assembly	168335	30B7046-01
PW306	Fuel Nozzle Assembly	155515	01R30B4952
PW306	Fuel Nozzle Assembly	155514	01R30B4951
PW306	Fuel Nozzle Assembly	168334	30B7045-01
PW306	Fuel Nozzle Assembly	179348	30B7079-01
PW306	Fuel Nozzle Assembly	179347	30B7078-01
PW307	Valve Assembly	154829	30P0565-03
PW307	Fuel Nozzle Assembly	155320	30P2100-01
PW307	Fuel Nozzle Assembly	155321	30P2103-01
PW307	Fuel Nozzle Assembly	165442	30P2626-01
PW307	Fuel Nozzle Assembly	165455	30P2625-01
PW307	Peanut Assembly	165455	30P2625-01
PW308	Fuel Nozzle Assembly	181633	30C6301-01
PW308	Fuel Nozzle Assembly	W1100490	30C6458-01

